

HOW TO FIT GENIEGRIPS® CAPS



STEP 1:

Raise Forktynes

SAFELY raise forktynes to waist height.

Ensure Caps are correct way up, with the metal surface at the top.



STEP 2:

Insert Caps

Approach tyne at 90 degree angle and slot the Caps on to the tip of fork tyne. Firmly push them on to tyne.



STEP 3:

Mallet installation

Once firmly on tyne, use rubber mallet to ensure the tip of the tyne touches inside back of cap.



STEP 4:

During use

Caps are now ready for use.

Important: When using the GenieGrips® Caps, licenced forklift drivers must enter the pallet at a 90 degree angle and allow sufficient clearance above and below tyne when entering/exiting to ensure Cap installation is not compromised.



STEP 5:

Removal and Storage

To remove, use metal rod and mallet to loosen and gently remove from fork tyne.



STEP 6:

Cleaning

Keep caps clean by using cleaning solution.

Store Caps in protective drawstring bag provided.



ALWAYS:

- Ensure GenieGrips® Caps are kept clean and free of contamination (eg grease, oil, paint, etc)
- Ensure forklift truck is only operated by licenced/trained personnel and in accordance with manufacturer's safe operating procedures.

