



# Sideways Drum Rotator (SDR)

In order to pick up a drum, drive slowly forwards into the attachment sleeves and secure via the screw downs. Set the girdle to the horizontal position by means of either the crank handle or loop chain. The girdle must then be positioned at a height such the girdle located inbetween the drums centre rolling hoops. Once the drum is fully located secure via the ratchet and webbing strap or the over centre steel clamp, depending on the model you have. Once the drum is lifted to the desired pouring position, the drum can be rotated via the crank handle or loop chain, the gearbox provided locks the drum at any desired angle to increase safety during operation.



CONTACT Roll Forward Skips come with the benefits of having a full length release handle accessible from either side; this eliminates the need to lean dangerously over the skip to activate it. This also means the skip can be tipped if positioned alongside a wall. Drilled castor plates allow for retro-fitting if required

Model Ref.	Capacity	No. Of Drums	Type of Operation	"A" Load Centre	"B" Fork Spread	"C" Pocket Length
SDR-1-SC	360kgs	1	Crank Handle	1360mm	685mm	1000mm
SDR-2-SC	360kgs	1	Loop Chain	1360mm	685mm	1000mm
SDR-1-DS	360kgs	1	Crank Handle	1360mm	685mm	1000mm
SDR-2-DS	360kgs	1	Loop Chain	1360mm	685mm	1000mm

Model Ref.	C of G	Weight
SDR-1-SC	695mm	112kgs
SDR-2-SC	695mm	118kgs
SDR-1-DS	695mm	112kgs
SDR-2-DS	695mm	118kgs

### Ordering Information

Truck Capacity                      Drum Type  
Fork Width/Thickness            Max Fork Spread  
Drum Weight                        Drum Diameter

